REV	REV DESCRIPTION						INITIAL	DATE	
00						1-18	KANG F	30 DEC 2013	
01						1-18	POH YT	26 SEP 2014	
02						1-17	POH YT	14 APR 2015	

REVISION TABLE

REVISION TABLE								
REVISION	DATE	SHEET	NAME	CHANGE DETAIL				
00	00 30-12-2013			first revision for 3D AOI system				
01	26-09-2014	1	CONTROL PANEL - MAIN POWER 220/110V	DRRECTION OF MCB CURRENT RATING (Q7)				
		8	CONTROL PANEL - GANTRY X- AXIS SERVO MOTOR DRIVE	CORRECTION OF X-AXIS MOTOR PHASE WIRE COLOUR				
		9	CONTROL PANEL - GANTRY Y- AXIS SERVO MOTOR DRIVE	CORRECTION OF Y-AXIS MOTOR PHASE WIRE COLOUR				
		13	STANDARD SMEMA	CORRECTION OF SMEMA PIN OUT ACCORDING TO IPC-SMEMA-9851				

V510 G2S


DRAWING STATUS:RELEASED									
NOTE:	DESCRIPTION:-	GENERAL TOLERANCE (UNLESS OTHERWISE	NAME	G2S ELECTRICAL DRAWING			REV:	01	
			PART ID	4SJCP-A004	DWG NO.	4SJCP-A004	SCALE:	NTS	
		X ± 1.00 X.X ± 0.50	-	INITIAL	SIGN	DATE			
		X.XX ± 0.30 X.XX ± 0.10 X.XXX ± 0.05	DRAWN BY	KANG F					
		X° ± 1° X.X° ± 0.5°	CHECKED BY	OOI SW					
THIS DOCUMENT IS THE PROPERTY OF VITROX TECHNOLOGIES SDN. BHD. IT SHALL NOT BE DISCLOSED OUTSIDE OF VITROX TECHNOLOGES PREMISES WITHOUT PRIOR AUTHORIZATION		UNIT IN MM	APPROVED BY	OOI SW			SHEET		


REV	REV DESCRIPTION						INITIAL	DATE		
00	New Release					1-18	KANG F	30 DEC 2013		
01	. Drawing Update, Refer To Revision Table For Details					1-18	POH YT	26 SEP 2014		
02	TUV Audit Update		1-18	POH YT	14 Apr 2015					


REVISION TABLE									
REVISION		SHEET	NAME	CHANGE DETAIL					
02	14-4-2015	1	CONTROL PANEL - MAIN POWER 220/110V	MAIN FILTER Z1 WIRE AWG, CURRENT RATING					
			CONTROL PANEL - Stepper Motor Drives	ADD RELAY KAS					
			CONTROL PANEL - GANTRY AC INPUT POWER	TEKNIC INCOMING WIRE AWG					
		6,7	CONTROL PANEL - GANTRY X- AXIS SERVO MOTOR DRIVE	COMBINED ALL SAFETY RELAY CONTACTS CIRCUIT IN A SHEET, ADD RELAY KAS AND CONNECT 3 EMERGENCY STOPIN SERIES WITH MAINTENANCE SWITCH					
		15	CONTROL PANEL LAYOUT (CENTER)	ADD RELAY KAS					


V510 G2S


						DRAWING STA	TUS:RELEA	ASED
NOTE:	DESCRIPTION:-	(UNLESS OTHERWISE	NAME	G2S ELECTRICAL DRAWING			REV:	03
			PART ID	4SJCP-A004	DWG NO.	4SJCP-A004	SCALE:	NTS
		X ± 1.00 X.X ± 0.50	-	INITIAL	SIGN	DATE		
		X.XX ± 0.10 X.XXX ± 0.05 X° ± 1° X.X° ± 0.5°	DRAWN BY	KANG F				
			CHECKED BY	OOI SW				
THIS DOCUMENT IS THE PROPERTY OF VITROX TECHNOLOGIES SDN. BHD. IT SHALL NOT BE DISCLOSED OUTSIDE OF VITROX TECHNOLOGES PREMISES WITHOUT PRIOR AUTHORIZATION			APPROVED BY	OOI SW			SHEET	



































115 110 112 113 114 117 118 119 116 REV DESCRIPTION SHEET NO. INITIAL DATE See Sheet 1 for Revisions STANDARD SMEMA SMEMA UPSTREAM RAIL 1 SMEMA DOWNSTREAM RAIL 1 PLC INPUT 24V GND PLC INPUT 24V GND KA13(198) KA14(199) (48) 436 438 WHITE_0.25mm² WHITE_0.25mm² PLC COMMON PLC COMMON / PLC COMMON 101.03 14 PIN XS6-SMEMA SOCKETS XS5-3 XS5-4 XS19-1 XS19-'2 XS5-1 XS5-2 X26-3 XS6-7 XS6-4 КАб XP5-1 XP5-2 XP5-3 XP5-4 XP19-1 XP19-2 XP6-3 XP6-4 XP6-7 UP AND DOWN STREAM MACHINES (P) ND NC 111 NO NC 114 ND NC 115 DRAWING STATUS: RELEASED GENERAL TOLERANCE DESCRIPTION:-NAME CONTROL PANEL - SMEMA Interface Cables labeled with 200-299 are RED_1mm², 300-399 are BLACK_1mm², 430-699 are SPECIFIED) PART ID 4SJCP-A004 DWG NO. SCALE: YELLOW_1mm² and 700-799 are GRN/YEL_2.5mm² unless otherwise stated. X ± 1.00 X.X ± 0.50 X.XX ± 0.10 INITIAL SIGN DATE DRAWN BY X.XXX ± 0.10 X.XXX ± 0.05 X° ± 1° X.X° ± 0.5° CHECKED BY

APPROVED BY

SHEET 13 OF 17







150 153 154 151 152 155 157 158 159 REV DESCRIPTION SHEET NO. __INITIAL DATE See Sheet 1 for Revisions SWITCH PLATE BACKVIEW YELLOW YELLOW YELLOW X5-10 X5-6 X5-11 X5-1 X5-6 X5-13 WHITE/GREEN RED BLUE PINK WHITE/YELLOW BLUE (3) 3 (X1 3 3 m Z (X2 WHITE VIOLET GREEN GRAY/PINK GRAY *RED/BLUE* BLACK YELLOW X5-12 X5-9 X5 - 7X5-2 X5 - 4X5-5 X5-14 X5-8 E-STOP RESET AWARAIL 1 SWITCH RUN START MAINT. SWITCH RESET LIGHT SWITCH IN/NUT BUTTON BUTTON BUTTON CONTACT CONTACT CONTACT CONTACT CONTACT CONTACT CONTACT DRAWING STATUS: RELEASED NOTE: DESCRIPTION:-GENERAL TOLERANCE (UNLESS OTHERWISE SPECIFIED) NAME SWITCH PLATE BACKVIEW (CONTACT BLOCK CONNECTION) REV: 00 PART ID 4SJCP-A004 DWG NO. 4SJCP-A004 SCALE: NTS X ± 1.00 X.X ± 0.50 X.XX ± 0.10 X.XXX ± 0.05 INITIAL DATE SIGN DRAWN BY CHECKED BY APPROVED BY SHEET 17 OF 17